




### Blastwheel Blades

| Shotblaster | Part #   |
|-------------|----------|
| SPE 12E     | 08001    |
| SPE 16E     | 16/08001 |
| SPE 20ES    | 02001    |



### Blastwheel - SPE 9G & SPE 9E

| Shotblaster     | Part # |
|-----------------|--------|
| SPE 9G & SPE 9E | 11302  |



### Hood Liner

| Shotblaster     | Part #   |
|-----------------|----------|
| SPE 9G & SPE 9E | 11004    |
| SPE 12E         | 08010    |
| SPE 16E         | 16/08010 |
| SPE 20ES        | 03002    |



### Side Liner

| Shotblaster     | Part #                    |
|-----------------|---------------------------|
| SPE 9G & SPE 9E | LH: 11006 RH: 11005       |
| SPE 12E         | LH: 08009 RH: 08008       |
| SPE 16E         | LH: 16/08009 RH: 16/08008 |
| SPE 20ES        | LH: 03001 RH: 03000       |



### Impellor

| Shotblaster     | Part # |
|-----------------|--------|
| SPE 9G & SPE 9E | -      |
| SPE 12E         | 08003  |
| SPE 16E         | 08003  |
| SPE 20ES        | 02003  |



### Control Cage

| Shotblaster     | Part # |
|-----------------|--------|
| SPE 9G & SPE 9E | 11301  |
| SPE 12E         | 08002  |
| SPE 16E         | 08002  |
| SPE 20ES        | 02002  |